## IMPORTANT SAFETY INSTRUCTIONS Please Read and Save These Instructions

WARNING – TO REDUCE THE RISK OF FIRE, ELECTRICAL SHOCK, OR INJURY TO PERSONS, OBSERVE THE FOLLOWING.

CAUTION – FOR GENERAL VENTILATING USE ONLY. DO NOT USE TO EXHAUST HAZARDOUS OR EXPLOSIVE MATERIALS OR VAPORS.

- Use this unit only in the manner intended by the manufacturer. If you have questions, contact the manufacturer.
- Before servicing or cleaning the unit, switch power off at service panel and lock service panel to prevent power from being switched on accidentally.
- Installation work and electrical wiring must be done by a qualified person(s) in accordance with all applicable codes and standards, including fire rated construction.
- Sufficient air is needed for proper combustion and exhausting of gases through the flue (chimney) of fuel burning equipment to prevent back drafts. Follow the heating equipment and safety standards such as those published by the National Fire Protection Association, the American Society for Heating, Refrigeration and Air Conditioning Engineers, and the local code authorities.
- Due to the size and weight of this unit, two installers are recommended.

- When cutting or drilling into the wall or ceiling, do not damage electrical wiring and other hidden utilities
- Ducted fans must always be vented to the outdoors. Do not vent to an attic or crawl space.
- WARNING TO REDUCE THE RISK OF FIRE, USE ONLY METAL DUCT WORK.
- Install this hood in accordance with all requirements specified.

## WARNING

- Never leave surface units unattended at high settings. Boil overs can cause smoking and greasy spillovers may ignite. Heat oils slowly on low or medium settings.
- Always turn the hood on when cooking on high heat or when flambéing or grilling foods.
- Clean filters frequently. Grease should not be allowed to accumulate.
- Use proper fan size. Always use cookware appropriate for the size of the surface element.

